



#### **EMCS** Assisted **Commissioning Tool** For Variable Air System







Http://lrdec.mets.rncan.gc.ca Daniel Choinière ing., 450-652-4874 dchoinie@nrcan.gc.ca





#### **Canadian Contribution:**

- IEA Annex 40, Commissioning of Building HVAC Systems for Improved Energy Performance
- IEA Annex 34, Computer-aided Evaluation of HVAC System Performance: the Practical Application of Fault Detection and Diagnosis Techniques in Real Buildings
- Acknowledgements: PERD, Natural Ressources Canada

## WHY? Commissioning, Re, On Going-Commissioning, Energy Management

- 15-30% energy savings
- Improve comfort
- Facilitate maintenance
- Continuity in energy savings measures
- Extend HVAC equipment life




#### **Outline**

- EMCS Assisted Cx Tool
- Methods
- Results
- Next steps

#### **Definitions**

On-going Commissioning Tool



- Detect unsatisfactory performance and diagnose faults
- Function of installed equipments and occupation type:
  - ◆ Optimize energy use, while maintaining or improving occupant comfort and productivity;


#### **EMCS Today**

■ Good to control system

■ Good to allow visualization in real time (if graphics are well configurated) ↑


■ Manage simple alarms

Simple monitoring




v ows

BACnet Fi



## Fault Detection and Diagnosis: Component Level

- Sensor (temperature, humidity, air flow, pressure, CO<sub>2</sub>, current)
  - ◆ incorrect reading, complete failure
- Damper, valve, actuator
  - ◆ stuck, position, minimum, leakage
- Coil, humidifier, fan
  - **♦** undercapacity
- Controller
  - ◆ logic, tuning, signal, unstable (setpoint, output)
- Point in manual








## Fault Detection and Diagnosis: System Level

- Detection of:
  - •under or over design components, systems and plants
  - ◆Non optimum set points
    - Temperature, pressure, humidity, ventilation, start-up time
  - ◆Inappropriate sequence of operation
  - ◆Poor energy management and peak load control


#### **Energy Auditing**

- Energy profile (Day, month and year)
  - Equipment level (TERMINAL, AHU, Power plant)
  - Building level (electric, gas, oil meter?)
  - Include adjustment and influence factors
  - ◆Monitoring of energy saving measures
  - ◆Historical database for energy audit or retrofit
  - ◆Real time energy audit
  - **◆**Link to accounting manager software
  - ◆FDD at building level (Tariffs, reference profile)

#### **Embeded Steady State Detector**



#### FDD Architecture, Component Level



## Fault Detection and Diagnosis: System Level

- Indice of performance:
  - ◆ With existing control points, find an equation that:
    - Characterize devices condition
    - Characterize devices utilisation
    - Allow comparison between devices



#### ■ Method:


- ◆ Analysis of Utilisation Factors
- ◆ Diagnosis method: Statistics and Rule base

#### Performance indice: Room Level

Indice	Optimisation, performance report	Detection,
Temperature (%)		
Air quality (%)	% of fresh air	
Damper position (%)	SAP	
Cooling (%)	SAT, SAP	Under and
Heating (%)	SHWT	overdesign
Reheating (%)	SHWT	components
Airflow (%)	SAP, SAT	Poor sequence of
Fault Code		operation
Fault type	Confort, energy, life	
	cycle	


#### Performance indice: Utilisation Factors, System level

- Supply, return Fan indice (vsd%)
- Airflow (airflow)
- Heating coil indice (%HC, Time on)
- Cooling coil indice (%CC, Time on)
- Reheat coil indice (%RHC, Time on)
- Humidifier indice (%HUM, Time on)
- Fresh air indice (%, calculation)
- Cooling indice
- Heating indice




#### U.F analysis: real time, 1H, 1 working periodetc..

- Between rooms in a same zone and AHU
- Between AHUs components (CC, HC)
- Between Chillers, Boilers




- Sort by Statistic methods, filters, etc
  - Depend, # and type of samples

### Calculation of Warning and Critical Limit Parameters, Reference Patern



- Could be constant or dynamic
- User define
- User define with DABO tool
- Calculate by DABO (Statistic, clustering method, etc.)

- Filter option in statistic calculation :
  - ◆ Devices (one or all)
  - ◆ Date
  - ♦ Hour
  - ◆ Outside air temperature
  - ◆ Outside air humidity
  - ◆ Solar (if sensor is available)



# iagnostic Agent for operators

▲ M3 Bureaux 1 Properties Configuration

Point name

BAS\_Building-Varennes\_M3 Bureaux 1\_SupplyAirSection\_AirFlow\_Status BAS\_Building-Varennes\_M3 Bureaux 1\_SupplyAirSection\_AirFlow\_SPStability

BAS\_Building-Varennes\_M3 Bureaux 1\_SupplyAirSection\_Humidity\_\_SetPoint BAS\_Building-Varennes\_M3 Bureaux 1\_SupplyAirSection\_Humidity\_\_Status

BAS\_Building-Varennes\_M3 Bureaux 1\_SupplyAirSection\_Humidity\_\_SPStability

BAS\_Building-Varennes\_M3 Bureaux 1\_SupplyAirSection\_Pressure\_\_SetPoint
BAS\_Building-Varennes\_M3 Bureaux 1\_SupplyAirSection\_Pressure\_\_Status

BAS\_Building-Varennes\_M3 Bureaux 1\_ReturnAirSection\_AirFlow\_\_SetPoint BAS\_Building-Varennes\_M3 Bureaux 1\_ReturnAirSection\_AirFlow\_\_Status

BAS\_Building-Varennes\_M3 Bureaux 1\_ReturnAirSection\_AirFlow\_\_SPStability BAS\_Building-Varennes\_M3 Bureaux 1\_ReturnAirSection\_Humidity\_\_SetPoint

BAS\_Building-Varennes\_M3 Bureaux 1\_ReturnAirSection\_Humidity\_Status BAS\_Building-Varennes\_M3 Bureaux 1\_ReturnAirSection\_Humidity\_SPStability

BAS\_Building-Varennes\_M3 Bureaux 1\_ReturnAirSection\_CO2\_\_SetPoint BAS\_Building-Varennes\_M3 Bureaux 1\_ReturnAirSection\_CO2\_\_Status

BAS\_Building-Varennes\_M3 Bureaux1\_ReturnAirSection\_Enthalpy\_\_SetPoint BAS\_Building-Varennes\_M3 Bureaux1\_ReturnAirSection\_Enthalpy\_\_Status

BAS\_Building-Varennes\_M3 Bureaux 1\_MixedAirSection\_Damper\_CommandPoint
BAS\_Building-Varennes\_M3 Bureaux 1\_MixedAirSection\_Damper\_Status
BAS\_Building-Varennes\_M3 Bureaux 1\_MixedAirSection\_Damper\_Stability

BAS\_Building-Varennes\_M3 Bureaux 1\_MixedAirSection\_Temperature\_\_SetPoint

BAS\_Building-Varennes\_M3 Bureaux 1\_MixedAirSection\_Temperature\_\_SPStability BAS\_Building-Varennes\_M3 Bureaux 1\_MixedAirSection\_Temperature\_\_Stability BAS\_Building-Varennes\_M3 Bureaux 1\_ExhaustAirSection\_Damper\_\_CommandPoint

BAS\_Building-Varennes\_M3 Bureaux 1\_MixedAirSection\_Temperature\_\_Status

BAS\_Building-Varennes\_M3 Bureaux 1\_SupplyAirSection\_Pressure\_\_SPStability BAS\_Building-Varennes\_M3 Bureaux 1\_ReturnAirSection\_Temperature\_\_SetPoint BAS\_Building-Varennes\_M3 Bureaux 1\_ReturnAirSection\_Temperature\_\_Status

BAS\_Building-Varennes\_M3 Bureaux 1\_ReturnAirSection\_Temperature\_\_SPStability BAS\_Building-Varennes\_M3 Bureaux 1\_ReturnAirSection\_Temperature\_\_Stability

BAS\_Building-Varennes\_M3 Bureaux 1\_SupplyAirSection\_CO2\_SetPoint BAS\_Building-Varennes\_M3 Bureaux 1\_SupplyAirSection\_CO2\_Status

<b>å</b> M3 I	Bureaux 1 Properties Cor	nfiguration							2
View	Thresholds - controller	Thresholds - sensors	Sensor Modul	General settings	Operating r	modes Fans	Points Setting	FDD_AHU_CS_H	
	Temper	ature rise accross supp	ıly fan		1	.5		°C	88
	Temper	ature rise accross retu	n fan		0	.5		°C	
	Supply	air temperature set poin	t reasonable va	lue					
	heat	ling mode	17.0		to 2	1.0		°C	
	free	cooling & cooling mode	13.0		to 1	9.0		°C	
	Zone air	temperature set point	easonable valu	9					
			18.0		to 2	6.0		°C	
	Fresh a	ir damper at min. positic	n		0	.0		%	
	Mixed a	ir damper position at mi	nimum fresh air		1	00.0		%	
	Percent	tage of fresh air at minir	num		1	5.0		%	
	Return	air humidity set point rea	sonable vale		3	5.0		%	
	Design	winter outdoor air temp	erature		-2	28.0		°C	200000
	Design	summer outoor air temp	erature		3	4.0		°C	
	Winter	night freeze protection s	shout off		5	.0		°C	
	Without	cooling device, OAT lim	it to satisfy ZAT	SP or SATSP	0	.0		°C	
		Atinimum rotur	air tomnoratur	o mintor 18 ft			·c		-

Print OK Cancel

View Thresholds - controller Thresholds - sensors Sensor Modul General settings Operating modes Fans Points Setting FDD\_AHU\_CS\_H

Address

V2.13.GV56

V2.13.IP6

V2.13.GV16 V2.13.IP25

V2.13.GV64

V2.13 GV23

V2.13 GV57

V2.13.GV29

V2.13.IP5

V2.13.0P4

V2.13.0P3

V2.13.GV25

V2.13.IP8

V2.13.GV87 V2.13.GV53

V2.13.GV29

PPM

PPM

Pa

BIN

BIN

BIN

PPM PPM

BIN

KJ/kg

V2.13.IP14

V2.13.IP15

V2.13.IP16 V2.13.GV90

GV\_DEBIT\_M3\_A1

GV\_ACCEPTABL\_CO2 CO2\_SUPPLY\_M3 GV\_PC\_TPD1\_M3

F\_IN\_COS\_TPD\_M3

GV\_PC\_SDR\_M3
GV\_DEBIT\_M3\_R1
F\_INS\_SDR\_M3
GV\_PC\_THR\_M3
THR\_M3
F\_INCOS\_THR\_M3
GV\_ACCEPTABL\_CO2

CO2\_RETURN\_M3

F\_INST\_FC\_M3

MOD\_EX\_DAMP\_M3

TTM\_M3

GV\_AHU\_M3\_RAE V2.13.GV41 1 MIX\_AIR\_DAMP\_M3 V2.13 POS\_MIX\_AIR\_DAMP V2.13.ip20 1

THA\_M3

TTR\_M3

w	Thresholds	- controller	Thresholds - sensors	Sensor Modul	General settings	Operating modes	Fans P	oints Setting	FDD_AHU_CS_H
	Fan		min. flow	max.	flow	min. ampere	(A)	m	ax. ampere (A)
	Supply Fan	200.0		5000.0		10.0		21.3	
	Return Fan	100.0		2000.0		1.0		3.5	
			Differential supply Maximum supply a Minimum supply ai Threshold SAPSP	ir static pressur r static pressur SAPS	e setpoint 150	5.0 0.0		L/s Pa Pa Pa	
			Minimum fresh air Threshold outside		100			L/s L/s	
			Threshold supply-r		75.			L/s	
			Maximum pressur	e drop across fi	Iter 100	0.0		Pa	
			Minimum pressure	drop across filt	ter 50.	0		Pa	
			Threshold SFV,RFV	and SFVS,RFVS	5.0			%	

M3 Bureaux 1 Properties Configurat	ion								>
fiew Thresholds - controller Thres	holds - sensors	Sensor Modul	General se	ettings	Operating modes	Fans Point	s Setting	FDD_AHU_CS_H	
Last service execution  Date/time of the last service executi 2003-09-19 07:53:04.838	ion			Execut	ion mode				
				● Ma	nual			GO	
				○ Au	tomatic				
-Execution rate				Execut	ion time				
○ Daly				From			17 / 0	7 / 2003 09 : 5	3 💆
O Hourly				То			17/0	7/2003 13:5	3 🖣
		Print	ОК	Ca	ncel				

#### **Demonstration Projects**











#### **FDD** report for AHU



#### MAT uncalibrated by - 3°C


						•	_												
M30 Bureaux 2 - 2003-09-25 at 15h																			
Fault 3: Supply air temperature sensor																			
Mode: Free cooling with/without mechanical cooling																			
Suggested action: Verify calibration of temperature sensor																			
Impact: Possibility of overcooled or overheated air temperature causing																			
room temperature control and increased terminal reheat if applicable																			
Rule 89: The supply air temperature is higher then the mixed air temperatu	re and																		
cooling coil valve is open																			
Fault 4: Temperature Sensors: Mixed																			
Mode: Free cooling with/without mechanical cooling																			
Suggested action: Verify calibration of temperature sensor or too much air stratification	ırı																		
Impact: Provide incorrect supply air temperature during free cooling and																			
system shut down as a freeze stat protection																			
Rule 09: The supply air temperature is higher then the mixed air temperatu	re and																		
cooling coil valve is open	i e anu																		
Rule 95: The outdoor air temperature is not equal to the mixed air tempera																			
the mixed air damper is fully open	<b>&amp;</b>																		<u></u>
the mixed all damper is fully open									Poir	nt va	alues	s							
Fault 5: Return air temperature sensor	105														-				
Mode: Free cooling with/without mechanical cooling	100																		
Suggested action: Verify calibration of temperature sensor	9f																		
Impact: Miscepresentation of zone temperatures leading to improper temperature	540																		
of supply air set point	86																		
Rule 91: The return air temperature is lower then the allowable minimum ru	80																		
temperature during free cooling	70																		
,	65																		
Fault 13: Mixed air damper failure	60																		
Mode: Free cooling with/without mechanical cooling	56	5																	
Suggested action: Verify damper, linkage, actuator, adjustment and leakage when close	Salues Salues																		
Impact: Reduction in free cooling capacity if stuck open and possibility of	S 4:	5																	
up if stuck closed	40	o																	
Rule 95: The outdoor air temperature is not equal to the mixed air tempera	35	5																	
The mixed air temperature is not equal to the mixed air tempera	30	о																	
the mixer all partiple is they then	25	<b></b>			÷						+								
Fault 14: Outdoor air damper fallure	20	o			·														
	15													-					
Mode: Free cooling with/without mechanical cooling	10	J		-	-														
Suggested action: Verify damper, linkage, actuator, adjustment and leakage when close		5																	
Impact: Reduction in free cooling capacity if stuck closed and possibility of																			
up if stuck open		1	1:30 12	2:00 12	2:30	13:00	13:30	14:00	14:3			15:30	16:00	16:30	17:00	17:30	18:00	18:30	
	-										ours								
	■ M.		Duilding- Building								_	LOAT :	BAS_Build	U M-					
	_ M.	VI BVS	_building	varonnos	_wao B	uroaux :	=_MDK0d	AIFS COTH	rom	poraturo		- OAT E	>ó_Raild	ing varo	mos_Out	ucorcon	union_l o	mporatur	0_
			ption: The	e outdoo	r alr te	этрөга	ture Is	not equ	al to th	e mixe	d alr te	этрөга	ture whe	n the m	ixed air	dampei	is fully	ppen	
	Param	eters us	ed																

#### **AHU-Fault: Wrong Humidifier Command**





#### **AHU Heating Valve Leak**



#### 🙈 AHU fault details

M30 Bureaux 2 - 2003-12-17 at 15h

Fault 24: Heating valve failure

Mode: Free Cooling


Suggested action: Verify damper, linkage, actuator, adjustment and leakage when closed

Impact: No control of heating coil, therefore no control of supply air

temperature

Rule 97: The supply air temperature is higher then the mixed air temperature the cooling coil valve is closed


#### **General Visual Report Structure**



#### Filters:


- ◆ Devices (one or all)
- **♦** Control points
- **◆** Indices
- Date
- Outside air temperature
- Outside air humidity
- ◆ Solar (if sensor is available)

#### **Daily Room Device Performance Report**




#### **Room Device optimisation report**

(To reset AHU Supply air pressure setpoint)




#### **Daily AHU Performance Report**




#### **AHU Optimiser Report:**

(To optimize heating supply water temperature)




#### VAV FDD Report 200 Dual Duct VAV Boxes



#### **Energy and Cost savings**





#### **EMCS Assisted Commissioning Tool**

- Monitors building control data
  - ◆ Could invoke sequence of tests
  - ◆ Normal operating data
- Performs advanced data analyses
- Detects faults, performs diagnosis and reports energy performance
- Generates detailed reports
- Implemented in stand-alone tools and/or embedded in EMCS

#### **Next Steps**

- Fine tuned expert rules in FDD-Component level
- Complete the FDD-System level
- Analysis of Demonstration project results

#### **FDD Report For VAV Boxes**

Graphic V	fiew M30 E	Bureaux 2	FDD report	VAN	/ Fault	s AH	IU FDI	D герс	ort															
S	ystem:					FI	оог:			•	Orier	ntatio	n:			•	Date	e: <b>02</b>	/ <b>07</b> /	2003		De	etails	
Name	System	Floor	Orientati		Averages for each hour											ır of t	of the day							
Name	System	FIUUI	Orientati		0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18 1	
405	M30 Bur	1	Ì	Т	22,7	22,7	22,6	22,5	22,5	22,3	22,2	21,2	21,1	22,6	24,0	23,3	22,9	22,7	22,7	22,5	22,3	22,4	23,6 24	
400	M30 Bul	1		SP	22,0	22,0	22,0	22,0	22,0	22,0	22,0	23,0	23,0	23,0	23,0	23,0	23,0	23,0	23,0	23,0	23,0	22,5	22,0 22	
1215	M3 Bure	1	P-W	T	23,8			23,8	23,8	_	23,4		_	_	21,9	_	22,3	<u> </u>	_	<del>-</del>	<del>-</del>	22,4	_	
			<u> </u>	SP	22,0	22,0	22,0	22,0	22,0	22,0	22,0		22,0	22,0	22,0	22,0	22,0	22,0	22,0	22,0		22,0		
1219	M3 Bure	1	P-W	SP	22,7	22,7	22,7	22,7	22,7 21.0	22,7 21.0	22,7	-		20,8 21,0	<del>-</del>		21,1 21,0	21,3 21.0	21,1 21.0	<u> </u>	<u> </u>	21,2 21.0	22,3 22 24 0 24	
			T	Т	23.6		23,6			,-		21,7	21,0	22.5								23,0	24 4 24	
1319	M3 Bure	1	P-E	SP	24,0			-	,-		24,0	24,0	24,0	24,0	24,0	<u> </u>	24,0	23,4	23,0	<u> </u>	<u> </u>	23,0		
Lab1	M2 Laba	1	С	Т	23,5	23,5	23,5	23,5	23,5	23,4	23,4	23,2	22,4	22,4	22,3	22,2	22,2	22,1	22,2	22,2	22,3	22,3	22,7 23	
Lanı	M2 Labo	1		SP	22,5	22,5	22,5	22,5	22,5	22,5	22,5	22,5	22,5	22,5	22,5	22,5	22,5	22,5	22,5	22,5	22,5	22,5	22,5 22	
Lab6	M2 Labo	1	С	T	25,4	,-	_	-		-	-	-	_	<u> </u>	<del>-</del>	24,2	_	<u> </u>	<del>l </del>	<u> </u>	<u> </u>	23,9		
			<u> </u>	SP	23,0	23,0	23,0	23,0	23,0	23,0	23,0		23,0	23,0	23,0	23,0	23,0	23,0	23,0	23,0	23,0	23,0		
Lab2	M2 Labo	1	С	SP	24,0 24,0	/ -	,-	24,1 24,0	24,1 24.0	24,1 24.0	24,1	24,0 24,0		23,0 24.0	<u> </u>	22,9 24,0	22,7 24,0	22,7 24.0	22,6 24,0	22,6 24,0	22,6	22,6 24 ft	23,1 23 24 0 24	
				Т				23,8						22.9	22,8	22,6	22.5	22.5	22.6	22.7	22.7	22.7	23.0 23	
Lab3	M2 Labo	1	С	CD	4 888	22.0	-	33.0	22,0	33.0	22.0	220	22.0	33.0	22,0	22,0	22,0	999999	22,0	32.0	22.0	22.0	22.0 24	
Fault lege	end				1 1200	andonouico	anaaaaaa	antononio	natatata'a'	uuntatati () (	en totala (CE	e e e e e e e e e e e e e e e e e e e	unitatititi	andtototi66	acatatata (GG)	andononico	untatati (di	anatatati 66	esantando	ood				
	Syste	em not rur	nning				T	emp.	Setpo	oint n	ot sati	isfied						Air	flow	unsta	ble			
	Airflow Se	etpoint not	t satisfied					Airflo	w Se	tpoint	unst	able							Nor	mal				